FEELME
PDF Manual

Please navigate to feelme.ai/ using your Chrome browser. If you do not have Chrome installed, you can download it from here: bit.ly/download.

Log in or Create an account then verify your email with the code sent to your email inbox.

Verify your email with the code sent to your email.

To access our services, you must have an active subscription. You can choose from our available packages or buy a top-with your subscription.

Complete your order by adding your account details, billingaddress and payment details with the secure interface.

Install our Video Watcher plug-in, this is required to analyse the streaming video in another tab, make sure that your plug-in is always updated to the latest available version.

We recommend pinning the Video Watcher plug-in to your browser toolbar for easier access to your settings. You can do this by clicking on the puzzle icon ⚙ located in the top right-hand corner of your Chrome browser.

Turn on your compatible interactive device and put it in WiFi or Bluetooth pairing mode. Ensure that your toy is not connected to any other app or desktop platform.

Select the kind of toy want to connect your Feelme to "Bluetooth connection. Select your device under "Available Devices". For WiFi, select the WiFi option and insert your connection key. Remember, avoid connecting your toy directly to your PC. Vibe method is only for the Onyn. Refer to page 7 for Onyn connection instructions.

When connected, you can click "Yes" and the device should move. Now you are all set up and can start watching your favorite videos.

Navigate to the "Channels" section in the side menu to explore a variety of compatible websites. This will open in a new tab. Make sure to keep Feelme is open at all times while streaming content.

You can select the pinned icon 🎬 located in the top right corner to adjust your settings.

Customize your settings based on your desired experience and personal sensitivity.

Auto Pilot is a setting where all activities react automatically, regardless of sexual activity in the video, and transmits a signal in order to delivers more streamlined experience with your interactive sex toy.

Sync Control is a setting that allows signals to be transmitted to your interactive sex toy consistently when there is and is not action in the video.

Manual Control is the setting where you want to have your interactive sex toy based on your own sexual sensitivity.Pause Device is a functionality that allows you to take a break during your session.

For the Onyn+ range on Windows, please follow the following instructions:

On Windows 10, go to "Start", then "Settings", then "Devices."

Make sure Onyn+ is not listed in the list of devices and the Onyn+ is off.

Turn on your Onyn+ and put it on Bluetooth mode. Keep in mind to disconnect your Onyn+ from any other device it was connected to beforehand.

Click "Add Bluetooth or Other Device," select "Bluetooth (Mice, keyboard, ...)," then select Onyn+ from the list.

If Onyn+ is not listed, turn Onyn off and on again. If it is still not listed, try restarting your PC. As soon as Onyn+ shows up in the "Add a device" list and is added/connected, you can close "System Settings."

Please return to Feelme.ai in your Chrome browser and follow the connection instructions provided on slide 09.